

## Crankshaft End Float, Check (Z 22 SE)

**Note:** Crankshaft and cylinder block base plate attached

1. Attach the dial gauge **MKM-571-B**.
  - Attach to one end face of the cylinder block using the bracket.
  - Position and adjust the dial gauge probe on the crankshaft.
2. Measure the crankshaft end float.
  - Move the crankshaft lengthways.
  - Permissible crankshaft end float: **0,092 - 0,24 mm**
3. Detach the dial gauge **MKM-571-B**.

