

Rear Wheel Arch Liner, Remove and Install



Remove

1. Secure both front wheels using chocks
2. Raise and support the vehicle
3. Remove the rear wheel
 - Remove 4 bolts, remove the locking bolt
 - Use special socket under the front bonnet
4. Remove wheel arch liner
 - Remove 6 screws



Install

5. Install wheel arch liner
 - Install 6 screws
6. Install rear wheel
 - Install 4 bolts, install locking bolt **90 Nm**
7. Remove support and lower vehicle
8. Remove chocks