
## Brake Caliper, Rear, Overhaul



## Remove

Brake caliper – see operation "Brake Caliper, Rear, Remove and Install".



Sleeve (3) from brake caliper.

Split bush (4) and boot (5) from brake caliper.


Boots (1) from bush (2).

Bush (2) from brake caliper.



## Clean

Guide bores in body of brake caliper with brake cleaner.





## Inspect

Removed components – replace as necessary.




Bush (2) to brake caliper – lubricate with silicone grease.

Boots (1) to bush (2) – lubricate with silicone grease.

Boot (5) and split bush (4) to brake caliper – lubricate with silicone grease.

Sleeve (3) to brake caliper – lubricate with silicone grease.





Brake caliper – see operation "Brake Caliper, Rear, Remove and Install".

