

Shift Cables, Remove and Install



Remove


Centre console – see operation "Centre Console, Remove and Install" in group C.

Shift cables (1) from shift lever and support bracket.

Shift cables (2) from transmission.

Cable support (3) from underside of vehicle – bolts.

Shift cables from vehicle – clips.



Install

Shift cables to vehicle – clips.

Cable support (3) to underside of vehicle – bolts.

Shift cables (2) to transmission.

Shift cables (1) to shift lever and support bracket.

Centre console – see operation "Centre Console, Remove and Install" in group C.



Adjust

Transmission shift linkage – see operation "Transmission Shift Linkage, Adjust".

