

## Air Cleaner Element, Change



### Remove


Wiring harness connector from intake air temperature sensor.

Hoses from throttle valve housing – clamps

Breather hose from cylinder head cover – clamp

Cover with intake lines from air cleaner housing – clips.

Air cleaner element



T 9595



### Install

Air cleaner element

Cover with intake lines to air cleaner housing – clips

Breather hose to cylinder head cover – clamp

Hoses to throttle valve housing – clamps

Wiring harness connector to intake air temperature sensor