


## Air Cleaner, Remove and Install



**Remove**


Underbody cover – see operation "Underbody Cover, Remove and Install" in Group A.



**T 9649**

Rear left-hand wheel from the vehicle

Rear left-hand wheel arch trim – see operation "Rear Wheel Arch Trim, Remove and Install" in Group A.



**S 0789**

Wiring harness connector from intake air temperature sensor.

Hoses from throttle valve housing – clamps


Breather hose from cylinder head cover – clamp

Cover with intake lines from air cleaner

housing – clips.

Air cleaner element

Air cleaner housing from vehicle – nuts



T 9595



**Install**

Air cleaner housing into vehicle – nuts

Air cleaner element

Cover with intake lines to air cleaner housing – clips


Breather hose to cylinder head cover – clamp

Hoses to throttle valve housing – clamps

Wiring harness connector to intake air temperature sensor


Rear left-hand wheel arch trim – see operation  
"Rear Wheel Arch Trim, Remove and Install" in  
Group A.

Rear left-hand wheel to the vehicle – bolts **90 Nm.**



S 0789

Underbody cover – see operation "Underbody Cover, Remove and Install" in Group A.



T 9649