

Side Grille, Remove and Install (Z 22 SE)



Remove

Side grilles (2) – rivet (1).



Install

Side grilles (2) – rivet (1).

