

Special Service Tools – Group M

KM-108 Remover/Installer

To remove and install steering shaft ball bearing

KM-210-B Steering Wheel Remover

To remove steering wheel

KM-507-C Remover

To remove tie rod end from hub carrier

MKM-610 Torque Wrench
1/2" Drive

Measuring range 30-130 Nm.


MKM-611 Torque Wrench
3/8" Drive

Measuring range 10-60 Nm


KM-J-22610 Pliers

To tighten retaining strap for folding covers


KM-108




KM-210-B




KM-507-C




MKM-610



MKM-611



KM-J-22610



T 9509