




### Block Diagram Speedster/VX220, model year 2003



**Components**

A1	Control unit - Airbag	H1.12	Telltale - High beam
A2	Control unit - Anti-lock Brake System	H1.17	Telltale - Brake system
A5	Control unit - Motronic	H1.19	Telltale - Turn signal lamp
A13	Control unit - Anti-theft warning system	H1.22	Indicator - Coolant temperature
A17	Control unit - Immobilizer	H1.23	Fuel indicator
B1	Switch - Brake fluid	H1.24	Tachometer
B2	Switch - Parking brake	H1.25	Speedometer - Electronic
B3	Switch - Oil pressure	H1.65	Warning buzzer
B6	Switch - Minimum capacity, coolant	H1.69	Telltale - Coolant level
G2	Alternator	H1.76	Telltale - Gear shift up/Anti-theft warning system
H1.1	Charging indicator lamp	P5	Sensor - Fuel tank content
H1.2	Telltale - Oil pressure	S3.1	Switch - High beam
H1.4	Telltale - Airbag	S3.2	Switch - Turn signal
H1.5	Telltale - Anti-lock Brake System	S6	Switch - Hazard light
H1.6	Telltale - Engine	S38	Contact switch - Driver door