Seat Belts

The driver and passenger are provided with three–point, inertia–reel seat belts. The automatic retractors are secured to the roll bar and incorporate pyrotechnic seat belt tensioners (see Section 4.4 "Airbag and Pyrotechnic Seat Belt Tensioner System").

A load limiting mechanism is incorporated in the automatic retractor. This mechanism allows a controlled amount of relaxation to occur in the seat belt if the load on the seat belt exceeds a certain level. The illustration shows the seat belt of the right seat. The seat belt of the left seat is similar.

