

Location in Vehicle

The illustration is shown overleaf.

- 1 Driver's airbag
- 2 Contact unit
- 3 Airbag control unit
- 4 Pyrotechnic seat belt tensioner (passenger's side illustrated).

4.4.2 Location in Vehicle (continued)



