

## Door Striker, Adjust



### Adjust

Door striker – loosen and tap door striker with plastic face hammer to align, then tighten door striker.

