

## Lock, Door, Remove and Install




### Remove

Door trim from door – see operation "Door Trim, Remove and Install".

Water vapour barrier from door.

Lock from door – screws.

Linkage from lock.



### Install

Linkage to lock.

Lock to door – screws.

Water vapour barrier to door.

Door trim to door.