Brake Pads, Inspect for Wear

Illustration shows front and rear brake pads on left side, right side is similar.



Remove

Wheels from vehicle – bolts.



Measure

Thickness of brake pads (excluding backing).

Minimum brake pad thickness (excluding backing) - **2.5 mm**.

Important: All four brake pads on an axle must be replaced if any brake pad is less than minimum thickness.



Install

Wheels to vehicle - bolts 90 Nm.

