


## Switches

The combination switches on the steering column are carried over from the Corsa-B.


A bank of switches is located in the instrument panel.



### 13.6 Switches (continued)


A pushbutton starter switch (1) is located in the centre of the instrument panel.

This switch is disabled via a relay, once the engine is running, to prevent subsequent engagement of the starter.



A pushbutton switch (1) is located in the steering column cowl to reset the odometer to zero and to control the brightness of the instrument illumination.





T 9156