

Anti-theft Warning System

General

An anti-theft warning system is installed as standard equipment and comprises the following:

- Control unit.
- Movement sensor in the passenger compartment. The sensor is a microwave type.
- Switches on the doors, front bonnet and engine cover.
- Light emitting diode in the centre console.
- Remote control; radio frequency type.
- Power sounder (Vauxhall only).