
Location of Components



- 1 Control unit, anti-theft warning system
- 2 Switch, engine cover
- 3 Sensor, anti-theft warning system
- 4 Light emitting diode, anti-theft warning system
- 5 Switch, driver's door (passenger's switch is similar)
- 6 Power sounder (Vauxhall only)
- 7 Switch, front bonnet.