

Disarming ATWS

The anti-theft warning system is disarmed by means of the remote control. When disarming the system, the turn signal lamps flash once.