

## Block Diagram

A13 Control unit, anti-theft warning system

B48 Power sounder

B121 Sensor, anti-theft

E3.4 Turn signal lamp, rear, left

E4.4 Turn signal lamp, rear, right

H1.19 Telltale, turn signal

H2 Turn signal lamp, front, left

H3 Turn signal lamp, front, right

H6 Turn signal lamp, side, left

H7 Turn signal lamp, side, right

S16 Switch, engine cover

S38 Switch, driver's door

S39 Switch, passenger's door

S126 Switch, front bonnet

V1 Diode, anti-theft warning system

X13 Diagnostic connector

