## Third Brake Lamp, Remove and Install



## Remove

Third brake lamp from rear header rail – clips (arrowed).


Harness connections from third brake lamp.



## Inetall

Harness connector to third brake lamp.

Third brake lamp to header rail – clips.



T 9142