

Licence Plate Lamp, Remove and Install



Remove

License plate lamp from rear clam shell – screws.


Harness from license plate lamp.



Install

Harness to license plate lamp.

License plate lamp to rear clam shell – screws.



T 9085