

## Telltale Switch, Handbrake, Replace




### Remove

Rear console – screws and harness connector.

Middle console from around handbrake and gearshift levers - screws.

Telltale switch (inset) from handbrake support bracket - bolt/nut and washer.

Harness connector from switch.



### Install

Harness connector to switch.

Switch to handbrake support bracket – bolt/nut and washer.

Middle console around handbrake and gear lever – screws.

Rear console – screws and harness connector.