

Horn, Remove and Install



Remove

Harness connector from horn.

Horn from panel – bolts.



Install

Horn to panel – bolts.

Harness connector to horn.

