

## Oil Temperature, Measure



**Remove**

Oil dipstick.



**Install**


Insert the measuring probe **KM-4119-GP** from **KM-4119** to approx. 1 cm above the floor of the oil pan through the oil dipstick tube.



**Measure**

Oil temperature.

The oil temperature depends upon the engine load. At high ambient temperatures or at very high engine speeds the oil temperature may reach approx. **150 °C**.



**Remove**

Measuring probe.



**Install**

Oil dipstick.