

Accelerator Pedal, Replace (Z 22 SE)

1. Open the bonnet.
2. Disconnect the battery.
3. Open the driver's door.
4. Detach the wiring harness connector (1).
 - Release the wiring harness connector in the direction of the arrow.
5. Remove the accelerator pedal.
 - 3 nuts (2)
6. Install the accelerator pedal.
 - Use new nuts.
 - Tightening torque **12 Nm**
7. Attach the wiring harness connector.
 - Secure the wiring harness connector(s).
8. Install the interior panelling on the lower instrument panel padding.
 - 2 bolts, 2 clips
9. Close the driver's door.
10. Connect the battery.
11. Reprogram the volatile memories.
12. Close the bonnet.

