

Trim Height, Front Suspension, Adjust

Adjustment of the trim height is not possible. Trim height, for purposes of checking geometry and making adjustments of wheel alignment, camber and castor, must be as follows:

Front **140 mm** below front end of chassis side rail.

Rear **140 mm** below rear end of chassis side rail.

These measurements approximate to a load consisting of driver, passenger and half a tank of fuel.