

Intermediate Pipe, Replace (Z22 SE)


**Install**

Chocks to front wheels.

Raise vehicle.


**Remove**

Diffuser panel (1) – 14 bolts, 2 clips.



S 0935

Intermediate pipe from catalytic converter – 3 nuts (1).



S 0938


**Remove**

Intermediate pipe from silencer – clamp (1).

**Install**

Intermediate pipe to silencer – clamp (1).


Important: Do not tighten clamp.

**Install**

Intermediate pipe to catalytic converter – 3 nuts (1).

Torque

Clamp for intermediate pipe to silencer – nuts.

**Install**

Diffuser panel (1) – 14 bolts, 2 clips.

Lower vehicle.

**Remove**

Chocks from front wheels.

