


# Heating, Ventilation

## Heating - Ventilation

### General

The heating and ventilation system distributes external air through the passenger compartment and provides temperature regulation of that air.

The illustration shows the air distribution system in the instrument panel.



T 9299