


Lower Panel, Fuel Tank

The fuel tank lower panel (1) is secured to the underside of the chassis frame, beneath the fuel tank.

The fuel tank lower panel is a structural part of the chassis unit.



- **Service**

Do not drive the vehicle without the fuel tank lower panel installed.