



Towing Eye

A towing eye can be installed in the front of the vehicle.

The towing eye is stowed under the front bonnet.



T 8969