




Speedster/VX220, model year 2003



Systems

DIAG	Diagnostic link	VOLT	Voltage distribution
------	-----------------	------	----------------------

Components

FB8	Fuse	FB19	Fuse
FB9	Fuse	FB21	Fuse
FB10	Fuse	FL3	Main fuse
FB11	Fuse	FL4	Main fuse
FB12	Fuse	FR1	Fuse
FB13	Fuse	FR3	Fuse
FB14	Fuse	V25	Diode - Back-up power
FB15	Fuse		

Connectors

X1	Main harness & Battery positive	X13	Diagnostic link
----	---------------------------------	-----	-----------------

Grounding Points

2	Battery
---	---------

Abbreviations

7.5A	7.5 Ampere	IRL	Interior lamp
30	Constant voltage	LSW	Light switch
AB	Airbag	MK	Engine cooling
ABS	Anti-lock Brake System	NSW	Fog lamps, front
DIAG	Diagnostic link	PKL	Parking lamps
DWA	Anti-theft warning system	STA	Start & Charging
EMP	Radio	WL	Hazard warning lamps
FB8	Fuse FB8	Z20LET	Engine Z20LET
FF	Trumpet horn	Z22SE	Engine Z22SE
FL	Front Lamps	ZIG	Cigarette lighter
IMO	Immobiliser	ZV	Central door locking
INS	Instrument		

Color codes

BK	Black	RD/BU	Red / Blue
BK/BN	Black / Brown	VT	Violet
BN	Brown	VT/BK	Violet / Black

BN/BU	Brown / Blue	VT/YE	Violet / Yellow
RD	Red	WH/YE	White / Yellow