


**Block Diagram Speedster/VX220, model year 2003**

Components

A1	Control unit - Airbag	H1.17	Telltale - Brake system
A2	Control unit - Anti-lock Brake System	H1.19	Telltale - Turn signal lamp
A4	Control unit - Multec	H1.22	Indicator - Coolant temperature
A13	Control unit - Anti-theft warning system	H1.23	Fuel indicator
A17	Control unit - Immobilizer	H1.24	Tachometer
B1	Switch - Brake fluid	H1.25	Speedometer - Electronic
B2	Switch - Parking brake	H1.65	Warning buzzer
B3	Switch - Oil pressure	H1.68	Telltale - Parking brake
B6	Switch - Minimum capacity, coolant	H1.69	Telltale - Coolant level
G2	Alternator	P5	Sensor - Fuel tank content
H1.1	Charging indicator lamp	S3.1	Switch - High beam
H1.2	Telltale - Oil pressure	S3.2	Switch - Turn signal
H1.4	Telltale - Airbag	S3.3	Switch - Headlamp flash
H1.5	Telltale - Anti-lock Brake System	S6	Switch - Hazard light
H1.6	Telltale - Engine	S38	Contact switch - Driver door
H1.12	Telltale - High beam	S39	Contact switch - Front passenger door