




Speedster/VX220, model year 2003



Systems

CIG	Cigarette lighter	IRL	Interior lights
DCS	Door contact switch	WA-F	Windscreen washer
HEAT	Heating	WI-F	Windscreen wiper

Components

E39	Lamp - Passenger compartment	S22	Switch - Wiper unit
K10	Relay - Wiper, windscreen (Stage 1/Interval)	S22.1	Switch - Wiper, windscreen
M12	Motor - Blower, passenger compartment	S22.2	Switch - Washer, windscreen
M16	Motor - Wiper, windscreen	S38	Contact switch - Driver door
M26	Pump - Washer, windscreen	S39	Contact switch - Front passenger door
R10	Cigarette lighter	S69	Switch - Blower, heating
R11	Preresistor - Blower, heating		

Connectors

X10	Main harness & Interior fan	X26	Main harness & Extension harness, contact switch - Front passenger door
X25	Main harness & Extension harness, contact switch - Driver door		

Grounding Points

2	Battery	5	Chassis rear
---	---------	---	--------------

Abbreviations

10A	10 Ampere	FB3	Fuse FB3
15A	15 Ampere	FB4	Fuse FB4
15A.	Ignition voltage (15A)	FB11	Fuse FB11
20A	20 Ampere	FB17	Fuse FB17
30	Constant voltage	FR1	Fuse FR1
50A	50 Ampere	INS	Instrument
DWA	Anti-theft warning system		

Color codes

BK	Black	GN/YE	Green / Yellow
BN/GN	Brown / Green	OG/PK	Orange / Pink

BU/GN	Blue / Green	OG/VT	Orange / Violet
GN	Green	RD/GN	Red / Green
GN/BK	Green / Black	RD/OG	Red / Orange
GN/BU	Green / Blue	VT	Violet
GN/GY	Green / Gray	VT/WH	Violet / White