


**3D Harness Diagram Speedster/VX220, model year 2003**

Components

A1	Control unit - Airbag	S4	Switch - Parking lamp
A12	Control unit - Central locking	S6	Switch - Hazard light
A14	Radio	S22	Switch - Wiper unit
A17	Control unit - Immobilizer	S38	Contact switch - Driver door
B36	Loudspeaker - Front, left	S39	Contact switch - Front passenger door
B37	Loudspeaker - Front, right	S69	Switch - Blower, heating
E39	Lamp - Passenger compartment	S76	Switch - Fog lamps, front
H1	Instrument	S87	Switch - Central locking (instrument)
S1	Switch - Starter	S122	Switch - Fog lamps, rear
S2	Switch unit - Light	S124	Switch - Starter button
S3	Switch unit - Steering column	S125	Switch - Illumination/Reset trip odometer

Connectors

X20	Main harness & Contact unit	X25	Main harness & Extension harness, contact switch - Driver door
X23	Main harness & Control unit - Anti-theft warning system	X26	Main harness & Extension harness, contact switch - Front passenger door
X24	Main harness & Control unit - Anti-theft warning system		